ASSURE THAT SEAT IS IN LOCKED POSITION PRIOR TO TAXI, TAKE OFF, AND LANDING. FAILURE TO PROPERLY LATCH SEAT AND HEED ALL SAFETY INSTRUCTIONS CAN RESULT IN BODILY INJURY OR DEATH.

WINTERIZATION KIT MUST BE REMOVED WHEN OUTSIDE AIR TEMPERATURE IS ABOVE 20 F.

STBY BATT
ARM
OFF
TEST
TEST

MASTER
ALT BAT
ON

AVIONICS
BUS 1 BUS 2
ON ON

DIMMING
SW / CB PANELS
STBY IND
PEDESTAL
AVIONICS

LIGHTS
BEACON OFF
LAND OFF
TAXI OFF
NAV OFF
STROBE OFF
FUEL PUMP OFF
PITOT HEAT OFF

WARNING PITOT HEATER MUST BE ON WHEN OPERATING BELLOW 40 F IN INSTRUMENT METEROLOGICAL CONDITIONS

QUARTZ

DUO flight panel

AVN FAN
AUDIO
NAV COM1
NAV COM2
ADF
A/P
FLAP
INST
AVN BUS1
AVN BUS2
TURN COORD
INST LTS

MAGNETOS
R L BOTH
OFF
START

GLARESHIELD LT

ALT STATIC AIR PULL ON

CARB. HEAT PULL ON

IN TRANS
GEAR DN & LOCKED
LANDING GEAR
UP
DN

THROTTLE PUSH OPEN

PROP PUSH INC RPM

MIX PULL LEAN

WING FLAPS
UP
10°
20°
FULL

CABIN HT PULL ON

CABIN AIR PULL ON

NOSE DOWN
NOSE UP
TAKE OFF
NOSE LEFT
NOSE RIGHT

OPEN
COWL FLAPS
CLOSE

HEADSETS

BOTH
TAKE OFF LANDING
ALL FLIGHT ATTITUDES

FUEL SELECTOR

LEFT
LEVEL FLIGHT ONLY

RIGHT
LEVEL FLIGHT ONLY

OFF OFF